


EXPLOSION-DRAWING / SPAREPARTS-OVERVIEW

EXPLOSIONSZEICHNUNG / ERSATZTEILLISTE



RELAXXNOW

VTX400 fan
VTX400 Ventilator

Number in explosion drawing	Item number	Description
1	RN_VTX400_01	Front shell
2	RN_VTX400_02	Power panel
3	RN_VTX400_03	Screw
4	RN_VTX400_04	PCB
5	RN_VTX400_05	Touch panel
6	RN_VTX400_06	Rear shell
7	RN_VTX400_07	Screw
8	RN_VTX400_08	Fan wheel shaft sleeve
9	RN_VTX400_09	Fan wheel
10	RN_VTX400_10	Motor
11	RN_VTX400_11	Synchronous motor
12	RN_VTX400_12	Cord fixed plastic parts

Nummer in Explosions-zeichnung	Artikelnummer	Beschreibung
13	RN_VTX400_13	Capacitor
14	RN_VTX400_14	Steering shaft
15	RN_VTX400_15	Screw
16	RN_VTX400_16	Power cord
17	RN_VTX400_17	Cable tie
18	RN_VTX400_18	Motor holder
19	RN_VTX400_19	Base
20	RN_VTX400_20	Circlip
not in drawing	RN_VTX400_Carton	Carton
not in drawing	RN_VTX400_Gift box	Gift box
not in drawing	RN_VTX400_Manual	Manual

VTX400 FAN / VTX400 VENTILATOR